

## *creating history*

In a world that is constantly moving,  
motion is essential for the development of mankind.

There will be no motion without time,  
and no time without motion.


Using motion in our watchwinders to keep time,  
gives the ability to create history today.

[WWW.BENSON-WATCHWINDERS.COM](http://WWW.BENSON-WATCHWINDERS.COM)

## USER GUIDE

**BENSON WATCHWINDERS**

B L A C K S E R I E S



### ROTOR SELECTION AND STATUS DISPLAY

Select the specific rotor to set your preferences. When the rotor is rotating the display shows "on".




### ROTATION DIRECTION

Select the specific rotation direction. The available options are clockwise (right), counter- clockwise (left) and alternate (both directions).



### START / STOP

Start or stop the specific rotor.



### TURNS PER DAY (TPD)

Select the TPD according to the requirements of your automatic watch(es). The following TPD are available:

600 TPD - 900 TPD - 1200 TPD - 1500 TPD - 1800 TPD - 2100 TPD



### LED LIGHT

Turn LED light function inside the watchwinder on or off.



### SPEED WINDING MODE

Select this function to speed-wind your automatic watch(es). The rotor rotates 30 minutes clockwise (right), 30 minutes counter-clockwise (left) and then pauses for 15 minutes. After six cycles it will exit the speed winding mode and return to the programmed settings.

## GENERAL INFORMATION


- The watchwinder has a "power off memory function". After the power is disabled the watchwinder will restore the set preferences when power is enabled.
- On the backside is a USB port. The USB function can be used to charge other devices such as a smart-watch, mobile phone, camera etc etc.

## HINTS

- Don't place or remove watches when the rotors do rotate. It may damage the gearing and motor.
- Please use the original adapter.
- Close the watchwinder door to avoid external influences (dust, humidity etc etc) and keep your watches safe by clicking the watch holder inside the watchwinder.

**BENSON WATCHWINDERS**

BLACK SERIES



### ROTOR SELECTION AND STATUS DISPLAY

Select the specific rotor to set your preferences. When the rotor is rotating the display shows "on".




### ROTATION DIRECTION

Select the specific rotation direction. The available options are clockwise (right), counter- clockwise (left) and alternate (both directions).



### START / STOP

Start or stop the specific rotor.



### TURNS PER DAY (TPD)

Select the TPD according to the requirements of your automatic watch(es). The following TPD are available:

600 TPD - 900 TPD - 1200 TPD - 1500 TPD - 1800 TPD - 2100 TPD



### LED LIGHT

Turn LED light function inside the watchwinder on or off.



### SPEED WINDING MODE

Select this function to speed-wind your automatic watch(es). The rotor rotates 30 minutes clockwise (right), 30 minutes counter-clockwise (left) and then pauses for 15 minutes. After six cycles it will exit the speed winding mode and return to the programmed settings.

## GENERAL INFORMATION

- The watchwinder has a "power off memory function". After the power is disabled the watchwinder will restore the set preferences when power is enabled.
- On the backside is a USB port. The USB function can be used to charge other devices such as a smart-watch, mobile phone, camera etc etc.

## HINTS

- Don't place or remove watches when the rotors do rotate. It may damage the gearing and motor.
- Please use the original adapter.
- Close the watchwinder door to avoid external influences (dust, humidity etc etc) and keep your watches safe by clicking the watch holder inside the watchwinder.

**BENSON WATCHWINDERS**

BLACK SERIES